


LM 96 Analogue Watt Meter 90°scale - LM



Applications

The Watt meters, LM96 are offered for the AC systems

-single phase

-3 phase balanced load 3 or 4 wire

-3 phase unbalanced load 3 or 4 wire

These instruments are suitable to indicate forward (export / out going) and reverse (import / in coming) power flow. They can be used both on sinusoidal and non - sinusoidal current.

These meters offer several advantages in Switchboard and Generating Set panels. Number of meters can be mounted in a Panel Cut out (Mosaic Mounting). The Bezel, Front window glass and Dial can be easily replaced

Applicable Standards

Nominal case and cutout dimensions for S 2419 **DIN IEC 61554** indicating electrical instruments Scale and pointer for electrical IS 1248 measuring instruments DIN 43802 Connections and Terminal markings for IS 1248 **DIN 43807** panel meters DIN 46200/46282 Terminal bolts / leads Clamp straps for connections DIN 46282 Safety requirements and protective IS 9249 DIN 40050 measures for Electrical indicating instruments and their acessories VDE 0110 **VDE 0410** IEC 529,IEC 1010

Performance specifications for direct acting indicating analogue electrical measuring instruments and their accessories

Front frames for indicating measuring instruments principle dimensions Technical conditions of delivery for electrical instruments.

UL Combustibility class

Mechanical strength (Free fall test, vibration test)

IEC 51/DIN EN 60051 DIN 43701

IS 1248

DIN 43718 DIN 43701

UL 94 V-O IS 1248, IEC 51 IS 9000 **VDE 041** IEC 1010 IS: 1248 IS: 9000 VDE / VDI 3540

Comply with following European directives

2004 / 108 / EC (EMC directive), 2006/95/EC (low voltage directive) & amendment amendment 93/68/EEC fo €€ Marking.

Scale and Pointer

Environmental conditions

Knife - edge pointer

0 ... 90° Pointer deflection Scale characteristics Linear Scale division Coarse-fine Scale length 97mm

Mechanical Data

Moulded square case suitable for Case details mounting in Control / Switchgear

panels, Machinery consoles.

Case material Polycarbonate, flame retardant and drip proof

as per UL 94 V-0.

Front facia Glass Colour of bezel Black

Position of use Vertical Mounting Clamp. Panel fixing

Stackable in a single cutout Mounting

Panel thickness > 1.5 mm

Hexagon studs, M4 screws and **Terminals**

wire clamps E3

Electrical Data

Measured quantity Active / Reactive Power Response time 4s max. Overload capacity (acc to IS:1248/ IEC 51) Continuously 1.2 times rated voltage / current 2 times rated voltage , 5 Sec max Short duration 10 times rated current ,5 Sec max

Power consumption(Approx)

Current path < 0.2 VA

Voltage path types

E1W, D1W, D1B, V1W, V1B < 3.0 VA E1B < 3.5 VA D2W. D2B < 3.4 VA V3W < 3.9 VA V3B < 4.3 VA Enclosures code IP 52 case

(IEC 529) IP 00 for terminals insulation class Group A according to VDE 0110

Rated insulation voltage 660 V Proof voltage testing 2 kV 300 VCAT III Installation catagory

(IEC 1010)

insulation resistance > 50 Mohm at 500 V d.c.

Accuracy at Reference Conditions

Accuracy class 1.5 according to IS:1248 (IEC 51/ DIN EN 60051)

Reference conditions

23°C + 2°C Ambient temperature Nominal position ± 1° Position of use

Input Full-scale power value Pw or Pb Feasibility factor "Lambda"=Pw/Ps or Pb / Ps Power factor Cos □ = 1_+ 0.01 for Watt meters &

Sin □ = 1_+ 0.01 for Var meters

Voltage Rated voltage + 2% 45-65 Hz (50 Hz +0.1% for E1B) Frequency Current 20% to 120% of rated current IS: 1248 (IEC 51/ DIN EN 60051) Others

Electrical and mechanical zero point in the meter are not necessarily identical. Zero adjustment should be done only when voltage is applied and current circuit not energised.

Nominal range of use Ambient temperature 10 ... 37°C

Position of use Nominal position + 50 Voltage Rated voltage + 15%

Cos \square = 1 to 0.5 (ind.) for active Power factor

power

Sin □= 1 to 0.5 (ind.) for reactive

power

45-65 Hz (50 Hz + 1% for E1B) Frequency External magnetic field At 0.4 kA/m,less than 6% of fiducial value (not as a

percentage class index)

Environmental Conditions

Climatic suitability Climate category II as per IS: 1248 (climatic class 3 according

to VDE / VDI 3540)

Operating temperature -10 ... + 55°C -25 + 65°C Storage temperature Relative humidity

< 75% annual average, non-</p>

condensing

Shock resistance 15g_n for pulse duration 11 ms Vibration resistance 10-55-10Hz for ampli. 0.15mm

(1.5 g at 50Hz)

Pollution degree

www.zimmer-instruments.com

Options

Case Front facia Colour of bezel Red index pointer

Position of use

Antiglare glass Red, Yellow, Blue, White Front adjustable on site on request 15°165°

Dial

Blank dial With initial and end values

marked

Special markings Numbering /Lettering. Division dials Basic divisions without

numbering. Red or green.

Colour markings/bands

Standard Measuring Ranges

Type	Active power	Reactive power
Single phase system	E1W	E1B
3 phase 3 wire system	D1W	D1B
balanced load		
3 phase 4 wire system	V1W	V1B
balanced load		
3 phase 3 wire system	D2W	D2B
unbalanced load		
3 phase 4 wire system	V3W	V3B
unbalanced load		

Selection of measuring range

Apparant power Ps is calculated from primary ratings of current transformer and voltage transformer.

In single phase network, Ps = V . I

where V = voltage between phase and neutral & I = line current. In three phase network, Ps = $\overline{3}\sqrt{V}$. I

where V = voltage between two phase & I = line current. Full scale value i.e range of the instrument (Pw = active power, Pb = reactive power) must be selected in such a way that the same remain between 0.5 times and 1.2 times the value of apparent power Ps.

Thus feasibility factor "Lambda" should be between 0.3 and 1.5 where "Lambda" = Pw/Ps or Pb/Ps

Full scale values shall preferably be selected from standard series according to DIN 43701, 1 - 1.2 - 1.5 - 2 - 2.5 - 3 - 4 - 5 - 6 - 7.5 - 8 and their decadic / decimal multiples.

Rated voltage

For Single phase(E1W, E1B):- 57.7, 63.5, 100, 110, 127, 220, 289, 380.

For Three phase (D1W, D1B, :- 100, 110, 220, 240, 380, 415, D2W, D2B, V1W, V1B, V3W,

V3B) 500.

The voltage will be considered as a phase voltage (between phase an neutral) in case of single phase meters and as a line voltage (between two phases) in case of multi phase (2 wire, 3 wire and 4 wire) meters.

1A OR 5 A Rated current

> If used on current transformer, please state transformer ratio on

the order


Safety Precautions

- 1) Instruments with damaged bezel or glasses must be disconnected from the mains.
- 2) Adequate safety clearance must be maintained to control panel fasteners and to sheet metal housing. If non insulated connector wires are used.
- 3) The back cover must be snapped into place after connector wires have been clamped for protection against accidental
- 4) Bezel, Scale and Glass may only be replaced under voltage free conditions.
- 5) Instruments to be used in grounded panel. Specifications are subject to change without notice(02/09)

Functional Principle

For active and reactive power measurement, a moving-coil indicator is used to indicate watts and vars for which an analogue DC signal is obtained from a power converter attached to the case of the indicator.

Schematic diagram




The power converter uses one, two or three for multiplier systems 2 depending on the measurement of balanced or unbalanced load AC systems. Current transformers 1 provide the input current to the multiplier circuit.

The multipliers form the product of the instantaneous values of current and voltage (TDM principle). The product resultant is integrated, thereby suppressing the AC ripple.

Subsequently product proportional output is delivered to 3. There the voltage is converted into Current, whose magnitude also depends on Feasibility Factor (λ).

Finally this current is fed to the moving coil movement, 4. For the instrument DC power supply is obtained from input voltage, 5.

Dimensions




Connections


Active Power


Reactive Power

E1W-single phase(one element)E1W-single phase(one element)




D1B-Three phase, three-wire AC supply with balanced load (one element)







V1W-Three phase, four-wire AC supply with balanced load (one element)


V1B-Three phase, four-wire AC supply with balanced load (one element)






D2W-Three phase, three-wire V1B-Three phase, three-wire AC supply with unbalanced loadAC supply with unbalanced load (two element) (two element)






V3W-Three phase, four-wire AC supply with unbalanced load (two element)

V3B-Three phase, four-wire AC supply with unbalanced load (two element)





Ordering Information

Туре	
LM	Watt and Var meter, 90°Scale
Front Dimension	
96	96mm x 96mm
Type E1W E1B	Single phase systems
D1W D1B	3 phase 3 wire system balanced load
V1W V1B	3 phase 4 wire system balanced load
D2W D2B	3 phase 3 wire system unbalanced load
V3W V3B	3 phase 4 wire system unbalanced load
Measuring Ranges	Specify while ordering
Rated voltages	Refer to table inside
Rated currents	1A, 5A
Front facia	Normal glass 1
	Antiglare glass ^{*3}
Colour of Bezel	Black ^{*1}
	Red, Blue, Yellow, White ^{*3}
Position of use	Vertical ⁻¹
	on request 15165°°3
Dial	Standard scale same as measuring range
	Blank dial with division ^{*3}
	Additional lettering on request ³
	Additional numbering on request ^{*3}
	Coloured marking red or green ^{*3}
	Coloured sector red or green ^{*3}
Logo	ZIMMER "

^{*1}Standard

Ordering Example

LM 96 D V3W for active power 3 phase 4 wire system unbalanced load,measuring range 0 ... 480 kW, voltage AC 440 V, for use on current transformer 600/5A.

ZIMMER INSTRUMENTS

G-42521, Str.26, Ballindamm, Hamburg, Germany

Tel.: +49 40 810 26 67 / 7201252

Fax: +49 40 7201253

Email: info@zimmer-instruments.com www.zimmer-instruments.com



entsOrderNo.LM_90_DegDatasheet-E1.R0-920805-43-2013-EN

¹³Please clearly add the desired specifications while ordering