

LF 72 | 96 Analogue Power Factor Meters - LF



© Zimmer InstrumentsOrderNo.LF\_90\_DegDatasheet-E1.R0-920805-43-2013-EN

# **Application**

The moving coil indicators and a phase angle adjuster are used to monitor changing power factor conditions on ir-reversible balanced load systems.

The power factor is indirectly determined by measuring the phase angle φ between current and voltage (both sinusoidal). However the indicators are calibrated in values of cosine of the angle φ. These meters offer several advantages in Switchboard & Generating Set panels. Number of meters can be mounted in Panel Cut out (Mosaic Mounting). The Bezel, glass and dial can be easily replaced.

### **Features**

- Knife edge pointer.
- Glass filled polycarbonate housing.
- Easily replicable glass and bezel.

# **Applicable Standards**

Nominal case and cutout dimensions for S 2419

indicating electrical instruments. **DIN IEC 61554** Scale and pointer for electrical IS 1248 measuring instruments. DIN 43802 Connections & terminal markings IS 1248 for panel meters **DIN 43807** DIN 46200/46282 Terminal bolts / leads DIN 46282 Clamp straps for connections. Safety requirements and protective IS 9249 measures for Electrical indicating **DIN 40050** instruments and their acessories. **VDE 0110** VDE 0410 IEC 529,IEC 1010 IS 1248

Performance specifications for direct acting indicating analogue electrical measuring instruments and their accessories.

Front frames for indicating measuring instruments principle dimensions.

Technical conditions of delivery for electrical instruments

UL Combustibility class. Mechanical strength (Free fall test, vibration test)

DIN 43701 DIN 43718

IEC 51/DIN EN 60051

DIN 43701

IEC 61010

UL 94 V-0 IS 1248, IEC 51 IS 9000 **VDE 041** 

Comply with following European directives :

2004 / 108 / EC (EMC directive ), 2006/95 /EC (low voltage directive) & amendment 93/68/EEC, Fo € Marking.

### **Scale and Pointer**

Pointer Knife - edge pointer Pointer deflection 0°... 90° Scale characteristics Non - Linear

Scale division Coarse-fine Lf96 Scale length I f72 61mm 97mm

Interchangeability Scales are interchangeble.

#### **Mechanical Data**

Case material

Case details Moulded square case suitable for mounting in Control / Switchgear

panels, Machinery consoles. Polycarbonate

flame retardant and drip proof

as per UL 94 V-0.

Front facia Glass Colour of bezel Black Position of use Vertical

Panel fixing **Mounting Clamps** 

Mounting Stackable in a single cutout

Panel thickness

Hexagon studs, M4 screws and **Terminals** 

wire clamps E3

## **Electrical Data**

Measured quantity Power Factor

Overload capacity (acc to IS: 1248/ IEC 51/ DIN EN 60051)

Continuously Short duration

Voltage circuit

Current circuit 10 times rated current for

for 0.5 sec, 9 overloads 10 times rated current for 5 Sec, 1 overload 2 times rated current for for 0.5 sec, 9 overloads

1.2 times rated current

2 times rated current for 5 Sec, 1 overload

Power consumption(Approx):-

Current path < 1.0 VA Voltage path < 3.0 VA Enclosures code IP 52 case

(IEC 529) IP 00 for terminals without

backcover

Insulation class Group A according to VDE 0110

Rated insulation voltage 660 V Proof voltage testing 2 KV Installation catagory 300 VCAT III

(IEC 1010)

Insulation resistance > 50 Mohm at 500 V d.c.

# Accuracy at Reference Conditions

Accuracy class 1.5 according to IS:1248 (IEC 51/ DIN EN 60051)

Reference conditions 23°C ± 2°C Ambient temperature

Position of use Nominal position ± 1° Waveform Sinewave **Distortion Factor** < 1 %

95...100 % rated current Current Warmup <sup>3</sup> 5 minutes at min 80% of rated current and 100 % of rated

voltage.

45-65 Hz for 3 phase

Rated voltage ± 2% Voltage Frequency 50 Hz +/ - 0.1%

Other Conditions as per

IS: 1248 (IEC 51/ DIN EN 60051)

Nominal range of use Ambient temperature

0 ... 50°C Position of use Nominal position + 5° At 0.4KA/m

External magnetic field Rated voltage + 15% Voltage Current 20 to 120 % of rated current 49-51 Hz for single phase Frequency

## **Environmental Conditions**

Climatic suitability Climate category II as per IS: 1248 (climatic class 3 according

to VDE / VDI 3540) -10 ... + 55 C Operating temperature

Storage temperature -25 .... + 65 C < 75% annual average, non-Relative humidity

condensing

15gn for pulse duration 11 ms Shock resistance Vibration resistance 10-55-10Hz for ampli. 0.15mm

(1.5 g at 50Hz) Pollution degree

## Analogue Power Factor Meters - LF

## **Options**

Case

Front facia Antiglare glass Colour of bezel Red, Yellow, Blue, White

Front adjustable on site Red index pointer on request 0°....180° Position of use

Dial

Blank dial With initial and end values

marked.

Special markings Numbering /Lettering. Basic divisions without Division dials

numbering.

Colour markings/bands Red or green.

# **Standard Measuring Ranges**

Types

E - Single Phase System

D - Three Phase System Balanced Load

**Measuring Ranges** 

COS φ cap 0.5....1...0.5 ind COS φ cap 0.8....1...0.3 ind COS  $\dot{\phi}$ cap 0.8....1...0.8 ind

### **Rated Voltage**

Following single phase and three phase voltages are available as standard. The voltages will be considered as a phase voltage(between phase & Neutral) in case of single phase meters and as a line voltage (between two phases) in case of 3 phase 3 wire or 4 wire meters.

Please specify the application (single ph. & 3 ph. 3 wire or 4 wire)

500 Rated Current 1A 5A

Non-Standard ranges available on request.

### **Accessories**

### Safety terminal protection

Full sized polycarbonate back cover to provide protection against accidental contact (hand and fingers). (acc. to IS 9249 VDE 0410)

#### **Functional Principle**

The measuring system comprises a moving coil indicator & phase angle converter attached to the case of indicating instrument. moving coil movements has pivots of very high hardness movement is suspended. between spring loaded saphire jewels. movement is properly shielded & critically damped by eddy currents induced in coil former.

# Schematic Diagram.




A current transformer 1 of the phase angle converter provides input current to the electronic circuit. Both the input voltage and the current are passed to a bistable filp-flop stage 2.


The pulse duty cycle of flip-flop is proportional to the phase angle .A low pass filter allows the mean value which is proportional to the phase angle and is fed to the moving coil movement 3.

### **Connections**


LF 72/96 Single phase



LF 72/96 three phase three wire balanced load



### **Dimensions**



Version: 1/01/I/XII/0410

Front in mm	Nominal Dimensi	ons, mm	Cutout, mm $I_1 \times I_2$	Installation Depth Including Terminal (t), mm	Installation Depth Incl. Full back Cover (f), mm
72 x 72	72 x 72	5.5	68 <sup>0.8</sup> x 68 <sup>0.8</sup>	82.5	_
96 x 96	96 x 96	5.5	92 <sup>0.8</sup> x 92 <sup>0.8</sup>	54	62.5

# **Safety Precautions**

- Instruments with damaged bezel or glasses must be disconnected from the mains.
- Adequate safety clearance must be maintained to control panel fasteners and to sheet metal housing. If non - insulated connector wires are used.
- The back cover must be snapped into place after connector wires have been clamped for protection against accidental contact.
- Bezel, Scale and Glass may only be replaced under voltage free conditions.
- 5) Instruments to be used in grounded panel.

# **Ordering Information**

Type LF	Power Factor meter	
Front Dimension		
72	72mm x 72mm	
96	96mm x 96mm	
Measuring Ranges	Refer to table inside	
	Full sized polycarbonate back cover	
Rated voltages	Refer to table inside	
Rated currents	1A, 5A	
Front facia	Normal glass <sup>*1</sup>	
	Antiglare glass <sup>*3</sup>	
	Polycarbonate glass <sup>*3</sup>	
Colour of Bezel	Black <sup>*1</sup>	
	Red, Blue, Yellow, White*3	
Position of use	Vertical <sup>¹¹</sup>	
	on request 0180°³	
Dial	Standard scale same as measuring range	
	Blank dial with division*3	
	Additional lettering on request <sup>*3</sup>	
	Additional numbering on request*3	
	Coloured marking red or green <sup>*3</sup>	
	Coloured sector red or green <sup>*3</sup>	
Logo	ZIMMER 11	

<sup>\*1</sup>Standard

## **Ordering example**

LF 96 for 3 phase 4 wire system balanced load, measuring range (  $\cos\phi$  ) cap 0.5...1...0.5 ind, rated voltage AC 230V, rated current 1A.

Specifications are subject to change without notice (07/09)

#### **ZIMMER INSTRUMENTS**

G-42521, Str.26, Ballindamm, Hamburg, Germany

Tel.: +49 40 810 26 67 / 7201252

Fax: +49 40 7201253

Email: info@zimmer-instruments.com www.zimmer-instruments.com



<sup>&</sup>lt;sup>13</sup>Please clearly add the desired specifications while ordering